



Message in a Speaker POS Micro



- 1 PIR Activation**
This indoor player is activated via PIR, when detecting movement. Change the detection field by rotating the top section (60°).
- 2 Indicator LED**
The LED indicates the players state.
- 3 Play Modes**
Set to sequential or looping playback.
- 4 Wall Mount**
Easily mount the player onto a suitable surface via rear mounts, or use the supplied ball and socket bracket.
- 5 Great Audio Quality**
Audio is output via an 8Ω/2W speaker with an inbuilt 2W amplifier. The player also includes a high quality 3.5mm jack output.
- 6 USB Port**
Plug in the Micro USB cable to charge/power the player.
- 7 Micro SD Card Slot**
Store your content with a Micro SD Card (128MB supplied). Or use the 64MB internal memory.
- 8 Power On/Off**
Turn the device on/off via the switch.
- 9 Volume Button**
Adjust the players volume with the built-in control.

Technical Information

Uploading your Content - Micro SD Card

1. If you wish to play content directly from a Micro SD Card, your audio files are simply stored in the root named 01, 02, 03 etc...

Uploading your Content - Internal Memory

1. If you wish to upload to the internal memory, first insert the Micro SD Card with your numbered tracks on.
2. Plug in the USB cable to power the unit. Press and hold the A button and then turn the player off (keep holding the A button).
3. Wait 2 seconds whilst keeping the A button held and then turn the player back on.
4. The LED light will then flash on/off and you can then release the A button. The LED will continue to flash during transfer.
5. Once the transfer is complete, the unit will play the first message.



Unit Weight	0.161Kg
Unit Dimensions	84 x 42 x 122mm (42mm Depth as standard, 72mm depth fully adjusted)
Power Supply	3.7V Lithium Battery with USB charger (adapter supplied)
Message Storage Medium	Micro SD Card - Max. 2GB (128MB supplied)
Internal Memory	64MB
Message Encoding Format	.MP3
Audio Bitrate	16-320Kbps
Audio Output	8Ω / 2W (Typical Value)
Headphone Audio Output	1 x 3.5mm audio jack
PIR Range	≤6m in 120° angle
Operational Current	Standby ≤65uA Playback ≤200mA
Battery Charge Duration	Full charge - 4 hours (with no operation / interruption)
Included	
1 x MIAS POS Micro Unit, 2 x Wall Mounting pieces, 1 x Power Adapter, 1 x USB Cable (USB to Micro USB), & 1 x Micro SD Card	

Play Modes

Mode A - Sequential Playback

Sequential will play your tracks in numerical order. Please follow the steps below:

1. Press and hold button A for 3 seconds.
2. The LED will flash to confirm the Mode selection.
3. Your player will now be in Sequential mode - Playing track 1 on the initial PIR trigger, then track 2 on the second trigger and so on...

Mode B - Looping Playback

Looping will play the same track each time the PIR is triggered (01). Please follow the steps below:

1. Press and hold button B for 3 seconds.
2. The LED will flash to confirm selection.
3. Your player will now be in Looping mode - Playing track 1 on the initial trigger, then a repeating track 1 on the second trigger and so on...

Related Products




Large PIR Sensor



Message in a Speaker



SoundClip-8



Small PIR Sensor